

## Liquid sampler c/w air driven pump and carry on frame



This DPM liquid sampler in system purge configuration allows the This DPW liquid sampler in system purge configuration allows the product being sampled by means of a built-in membrane pump. The liquid medium is pumped continuously through the sampler to ensure the retrieval of a representative and contamination free sample. The carry on frame c/w flexible hoses and quick connects create a portable sampler ideal for sampling liquids on board ships.

## **BASIC SPECIFICATIONS**

Material	SS316(L).
Sleeve Type	500cc sleeve with bottle retaining clip. Larger/smaller sample size available.
Needle Assembly	Single piece VTO needle assembly with vent to outlet connection ¼" F NPT. Process/Vent needle ID: 1.35 mm.
Valve	Three-way ball valve. Type dependent on the product to be sampled.
Operation	Manual.
Connections	Process in/out: flexible hoses with quick connect couplings.
	Vent: ¼" F NPT, c/w adapter suitable for A2 gas filter.
	Air inlet pump: ¼" F NPT.

Dovianus B.V. Tel. Leeuwenhoekweg 24 2661 CZ Bergschenhoek

+31 (0)10 524 2000 dopak@cranecpe.com website www.dopak.com

e-mail